
New Zealand Fire Service Fire Research & Investigation Unit



FIRE RELATED PRODUCT RECALL NOTIFICATION

Fisher & Paykel DW60CS and DW60CD dishwashers	
15 August 2012	2 ACTION - New Zealand recall
Problem	A water leak could develop around the door latch area causing water to collect around the door handle and switch.
	This may cause a fire or melting of components within the handle.
Details	Fisher & Paykel dishwashers, manufactured between 2006 and 2008.
	The affected dishwashers have a model number starting with "DW60CS" or "DW60CD" and a serial number starting with "FA6", "FA7" or "FA8".
	The model and serial numbers can be found on the left hand side of the door.
What to do	Do not use the dishwasher unless you are present to monitor (for leaks or smells) or if there is excessive water on the handle. If there is excessive water on the handle or if you detect smoke/smells immediately stop using the dishwasher and switch it off at the wall.
	Visit www.fisherpaykel.com/recall , call 0800 080 776 or email specialist.team@fisherpaykel.com to register your model and serial number and arrange a service technician to replace the necessary part free of charge.
More Information	Call 0800 080 776 Consumer website

This notification has been compiled using information from external sources for the promotion of fire safety. Although care has been taken in preparing the information published, the New Zealand Fire Service does not guarantee the accuracy of it. The Fire Service is not responsible for any errors or omissions and accepts no liability whatsoever for any loss or damage howsoever arising.



This notification has been compiled using information from external sources for the promotion of fire safety. Although care has been taken in preparing the information published, the New Zealand Fire Service does not guarantee the accuracy of it. The Fire Service is not responsible for any errors or omissions and accepts no liability whatsoever for any loss or damage howsoever arising.